


USER'S GUIDE

YP15668(MULTIFUNCTION SPORT LCD WATCH)



BUTTONS


- The operation of buttons are indicated using the letters shown in the illustration.



- A -- Reset
- B -- Mode
- C -- EL backlight
- D -- Start / Stop

DISPLAY

- The screen shown in below:



ATTENTION

- Never try to open the case or remove its back cover.
- Do not operate buttons underwater.
- Should moisture appear inside the watch, have it checked immediately by your dealer. Otherwise it can cause erosion of the metal parts of the watch.
- Though the watch is designed to withstand normal use, you should avoid rough use or dropping the watch.
- Avoid exposing the watch to temperature extremes.
- Wipe the watch with dry, soft cloth only. Avoid allowing it to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.
- Avoid to wear the watch in electromagnetic, static conditions.

MODE SELECTION

- Press "B" to change mode to mode in the following Sequence:
Timekeeping Mode → Stopwatch Mode → Alarm Mode → Time Setting Mode.

a TIMEKEEPING

- Hour, Minutes, Seconds, Day of week;
- Built in Date.

b STOPWATCH

- 1/100 second unit;
- Measuring range: 0'00"00 ~ 23:59'59".

c ALARM

- The alarm sounds at the preset time each day;
- Hourly time signal;
- Snooze for 5 minutes.

d TIME SETTING

- Hour, Minutes, Seconds, Month, Date, Day of week can be set.

BACKLIGHT

- The backlight that uses an EL (electroluminescent) cause the display to glow for easy reading in the dark.

Use EL Backlight

- In any mode, press "C" to illuminate the display about 3 seconds.

a TIMEKEEPING

Display The Date

- In the timekeeping mode, press and hold "D" to display the date.



On/Off The Alarm

- In the timekeeping mode, press and hold "A" display the alarm time;
- Press "D" at the same time to on/off the alarm.



On/Off The Chime

- In the timekeeping mode, press and hold "A" display the alarm time;
- Press "B" at the same time to on/off the chime.



b STOPWATCH

A Lap Time

- In the stopwatch mode, press "D" to start the stopwatch;
- To stop the stopwatch by pressing "D" again;
- Press "A" to reset the stopwatch.



Split Time

- In the stopwatch mode, press "D" to start the stopwatch;
- Press "A" to display the split time, stopwatch timing continues internally;
- Press "A" to clear the split time and to continue time measurement;
- Repeat step 2 and 3, you can measure the multi split time;
- Press "D" to stop the stopwatch.



c ALARM

Alarm Time Setting

- In the alarm mode, the hour to flash;
- Press "D" to increase the hour, press and hold to increase at high speed;
- Press "A" to select the minutes;
- Press "D" to increase the minutes, press and hold to increase at high speed;
- Press "B" to return the timekeeping mode, after you set.



Snooze

- The alarm sounds at preset time each day for about 60 seconds;
- Press "D" to break it, the alarm continue after 5 minutes;
- Press "A" to stop it.

d TIMESETTING

Time Setting

- In the time setting mode, the seconds to flash;
 - Press "D" to reset the seconds;
 - Press "A" change to the next selection;
 - Press "D" to increase the number, press and hold to increase at high speed;
 - Repeat step 3 and 4, the selection in the following sequence: Seconds → Minutes → Hour → Date → Month → Day of week;
 - Press "B" to return the timekeeping mode, after you set.
- 12 / 24H formats can be selected, when hour setting.

