


USER'S GUIDE

YP12575(SECONDS CARTOON,MULTI FUNCTION SPORT WATCH)



BUTTONS


- The operation of buttons are indicated by using the letters shown in the illustration.



- A -- Reset
- B -- Mode
- C -- EL backlight
- D -- Start / Stop
- E -- EL backlight

DISPLAY

- The screen shown in below:



ATTENTION


- Never try to open the case or remove its back cover.
- Do not operate buttons under water.
- Should moisture appear inside the watch, have it checked immediately by your dealer. Otherwise it can cause erosion of the metal parts of the watch.
- Though the watch is designed to withstand normal use, you should avoid rough use or dropping the watch.
- Avoid exposing the watch to temperature extremes.
- Wipe the watch with dry, Soft cloth only. Avoid allowing it to come into direct contact with chemical materials, which can cause deterioration of the plastic parts of the watch.
- Avoid to wear the watch in electromagnetic, static conditions.

MODE SELECTION

- Press "B" to change mode to mode in the following Sequence:
Timekeeping Mode → Alarm Mode → Stopwatch Mode → Dual Time Mode.


a TIMEKEEPING

- 12/24H Format;
- Hour, Minutes, Seconds, Day of week, Date;
- 100 years Calendar (2000 ~ 2099).




b ALARM

- Hourly time signal;
- The alarm sounds at the preset time each day.



c STOPWATCH

- 1/100 second unit;
- Measuring range: 0'00'00 ~ 23:59'59".



d DUAL TIME

- The time for other time zone.



a TIMEKEEPING


12/24H Format

- In the timekeeping mode, press "A" to switch between 12/24H formats.




Calendar

- In the timekeeping mode, press and hold "D" to display: Year, Month, Date.



Time Setting

- In the timekeeping mode, press and hold "A" until the seconds to flash; (flashing indicated in set mode)
- Press "D" to reset the seconds;
- Press "B" change to the next selection;
- Press "D" to increase the number, press and hold to increase at high speed;
- Repeat step 3 and 4, the selection in the following sequence:
Seconds → Hour → Minutes → Year → Month → Date;
- Press "A" to exit the set state, after you set. (The day of week is automatically displayed in accordance with year, month and date setting)



b ALARM




Alarm and Chime

- In the alarm mode, press "D" to on/off the alarm and chime in the following sequences:
Alarm & Chime off → Alarm on → Chime on → Alarm & Chime on.



Alarm Time Setting

- In the alarm mode, press "A" the hour to flash, the indicator "A" appear; (flashing indicated in set mode)
- Press "D" to increase the hour, press and hold to increase at high speed;
- Press "B" to select the minutes;
- Press "D" to increase the minutes, press and hold to increase at high speed;
- Press "A" to exit the set state, after you set.



- The alarm sounds at the preset time each day for about 60 seconds, press any button to break it.

c STOPWATCH

A Lap Time


- In the stopwatch mode, press "D" to start the stopwatch;



- To stop the stopwatch by pressing "D" again;





- Press "A" to reset the stopwatch.



Split Time



- In the stopwatch mode, press "D" to start the stopwatch;
- Press "A" to display the split time, stopwatch timing continues internally;
- Press "A" to clear the split time and to continue time measurement;
- Repeat step 2 and 3, you can measure the multi split time;
- Press "D" to stop the stopwatch.



d DUALTIME

Dual Time Setting

- In the dual time mode, press "A" the hour to flash; (flashing indicated in set mode)
- Press "D" to increase the hour, press and hold to increase at high speed;
- Press "B" to select the minutes;
- Press "D" to change the minutes; (press once change 30 minutes)
- Press "A" to exit the set state, after you set.

